

The compact combination of power and style

Make the most of your kitchen space with a microwave that includes a fan oven and grill too. Part of the Electrolux compact range, our combi microwave lets you defrost, heat, roast, crisp and brown – all in one versatile, stylish design.

Product Benefits & Features

Merge cooking methods for quicker meals

Combine two types of power at once – traditional oven and microwave – to cook faster. The microwave shortens cooking times while the fan browns and preserves texture simultaneously, making tempting meals in a fraction of the usual time.

Immediate feedback on how your dish is doing

Just shoot one quick glance at this microwave's clear digital display and you'll get immediate feedback on how your dish is doing.

- Microwave for fully integrated built-in installation
- Built-in possibilities in combination with other appliances: Below worktop, Over oven
- Door opening mechanism: Push control
- Cooking modes: Convection, Grill, Microwave, Microwave & Convection,
- Microwave & Grill • Microwave power: 900 Watt, 9 levels
- Grill power: 1100 Watt
- Automatic defrosting programs by weight
- End of cook cycle signal
- · Automatic cooking programs by weight
- LED display
- Touch control power selection
- Turntable diameter and material: 315 mm, Glass
- Included accessories: Grill rack



Cook without thinking using the auto-programs When you're having a busy day, just take advantage of these auto-programs. They make sure you always use the right power levels, reducing the risk of mistakes.

More flexibility on when to decide what to cook for dinner Ingredients still in the freezer? With the intuitive power settings on this microwave, you can defrost food quickly, whenever you want, so it's ready when you are.



Microwave Oven **EMT255070X**

Product Specification

Product Installation	Built_In
Product Typology	Microwave_Oven
Product Classification	Performance
Installation	FBI
Design family	BlueFire
Main colour	Stainless Steel
Cavity colour	Stainless Steel
Window colour	Transparent
Display guide	LED
Type of timer min.	95 min
Power levels	9
Type of power control	Touch control
Touch controls nø of	12
Push controls nø of	1
Cooking modes	Convection, Grill, Microwave, Microwave & Convection, Microwave & Grill
Door open mechanism	Push control
Start/Stop control	Touch control
Turntable	Non-integrated
Signals	End signal
Defrost by time	Universal programme
Defrost by weight	Universal programme
Cooking	Microwave/Grill/Convection

Cooking by weight	Beverage, Fish, Meat, Pasta, Popcorn, Potatoes
Height total	388
Depth mm	470
Width mm	595
Voltage	230
Frequency	50
Required fuse (A)	10
Cord length external	1.3